

INSTALLATION INSTRUCTIONS

THE VOICE



 YOU TYPE
"HELLO" IT TALKS!

EDUCATIONAL
GAMES $\div \times =$
+ "ASK"

REALISTIC
GAME EFFECTS

 "HELP!"



ODYSSEY² SPEECH & SOUND EFFECTS MODULE



Copyright ©1982 North American Philips Consumer Electronics Corp.
Odyssey is a trademark of the Magnavox Company.

-
- 1 Be sure the Power Button on the Odyssey² console is in the OFF (UP) position. This will protect the electronic components of both the Console and the Synthesizer.



Important! For best performance replace your Odyssey² AC adapter with the new one enclosed. (If your present adapter has a male plug, a special plug adapter is included.)


YOU TYPE
IT TALKS!
"HELLO"

EDUCATIONAL
GAMES $\div \times =$
+ "ASK"



REALISTIC
GAME
EFFECTS

"HELP!"




THE VOICE


- 2 Insert the Synthesizer carefully into the cartridge slot of the Console. Guide it in firmly but without using force. (See illustrations #1 & #2.)
 - 3 Insert a game cartridge into the cartridge slot of the Synthesizer. Press the Power Button and activate the cartridge by following its accompanying instructions.
 - 4 Adjust the volume control. Slide it to the right to increase volume. Minimum volume will be heard when the control is in the far left position.
 - 5 All Odyssey² cartridges may be played through the Odyssey² Voice synthesizer. If you are playing a game that is not in the Voice Series, slide the volume control all the way to the left to minimize unwanted noise.
 - 6 **IMPORTANT!** Do not remove the Synthesizer once it is fitted into the console. This can cause unnecessary wear on the connecting components. If you should ever find it necessary to remove the Synthesizer, be sure the power is turned off.
-



THE VOICE

- 7 You can use a soft, slightly damp cloth to clean the exterior of the Synthesizer and the Console. DO NOT IMMERSE IN WATER. Clean up any liquid spills promptly.
- 8 Do not expose the Synthesizer, Console or hand controls to extreme heat.
- 9 Be sure the Power Button is in the OFF (UP) position when your Odyssey² is not in use, then unplug the AC adapter from the 120V outlet.





21 22 23 24 2

32

0283-MAR

IB 3977-1 AC 7605

How To Get Service On Your Odyssey² Voice Module After The Three Month Warranty Expires

Before returning your Odyssey² Voice Module for repair, verify there is a defect by reviewing the Owner's Manual.

If a defect exists out-of-warranty service can be obtained by returning your Voice Module to the nearest Odyssey² Service Center under the following arrangements:

1. Pack your Unit in the original carton. If that carton is not available, pack securely in a suitable container with newspaper or excelsior padding all around it.
2. Print the name and address of Odyssey² Service Center nearest you on the outside of the carton. (Please refer to the list shown below.) Don't forget to also show your return address.
3. Place a letter describing the Unit's problem in an envelope. Be sure that the letter includes your name and address. Enclose your check or money order for \$29.95** to cover the cost of repair or replacement and handling.
 - a. When shipping by parcel service, insert the envelope with the letter and payment just inside the top carton flaps, secure the carton according to the shipper's specifications, and forward to the nearest Odyssey² Service Center by pre-paid transportation.
 - b. When shipping by Parcel Post, place first-class postage on the addressed envelope with the letter and the payment and paste it to the outside of the carton. Place parcel postage on the package and mail.
4. When your Unit is received, it will be repaired or replaced by a renewed one which meets the original high quality standards and shipped by prepaid transportation.

ODYSSEY² SERVICE CENTERS

LOS ANGELES CENTER

N.A.P. Consumer Electronics Corp.
2649 Maricopa Street
Torrance, CA 90503

CHICAGO CENTER

N.A.P. Consumer Electronics Corp.
7500 Frontage Road
Skokie, IL 60076

NEW YORK CENTER

N.A.P. Consumer Electronics Corp.
180 Manor Rd., Dept. 102
East Rutherford, NJ 07073

ATLANTA CENTER

N.A.P. Consumer Electronics Corp.
1898 Leland Drive
Marietta, GA 30067

CLEVELAND CENTER

N.A.P. Consumer Electronics Corp.
24092 Detroit Road
Westlake, OH 44145

**Price effective through December 31, 1982.

ODYSSEY² VOICE MODULE LIMITED WARRANTY

This ODYSSEY² Voice Module is warranted to be free from defects in materials and workmanship for three (3) months from the date of sale to the original owner.

If, during the warranty period, the Voice Module fails to operate as designated in the Owner's Manual and you have followed the instructions in the Owner's Manual, you should either return the Unit to the selling dealer for inspection or carefully pack and ship it by pre-paid transportation with evidence of the purchase date to the nearest ODYSSEY² Service Center.

Any Voice Module found to be defective shall either be repaired or be replaced by a new or renewed Unit which meets the original high quality standards. Replacements are warranted for the balance of the original warranty period.

This warranty applies only when the product is purchased and serviced within the United States and when it is subjected only to normal use. The Warranty does not cover an ODYSSEY² Voice Module used in commercial applications nor does it cover a Unit which has been damaged or modified.

ODYSSEY² SERVICE CENTERS

LOS ANGELES CENTER

N.A.P. Consumer
Electronics Corp.
2649 Maricopa Street
Torrance, CA 90503

CHICAGO CENTER

N.A.P. Consumer
Electronics Corp.
7500 Frontage Road
Skokie, IL 60076

NEW YORK CENTER

N.A.P. Consumer
Electronics Corp.
180 Manor Rd., Dept. 102
East Rutherford, NJ 07073

ATLANTA CENTER

N.A.P. Consumer
Electronics Corp.
1898 Leland Drive
Marietta, GA 30067

CLEVELAND CENTER

N.A.P. Consumer
Electronics Corp.
24092 Detroit Road
Westlake, OH 44145

IMPORTANT

This warranty gives you specific legal rights, and you may also have other rights that vary from state to state. If at any time during the warranty period, satisfactory repair was not provided after you delivered or shipped your Module to the location designated in this warranty, please contact the nearest Consumer Affairs Office identified on this page.

CONSUMER AFFAIRS

If for any reason, you are dissatisfied with the repair service furnished on your ODYSSEY² Warranty, call or write to the N.A.P. Consumer Electronics Corp., Consumer Affairs Manager, at:

Los Angeles Division

2645 Maricopa Street
Torrance, California 90503
Phone: 213/320-8990

New York Division

180 Manor Rd., Dept. 101
East Rutherford, New Jersey 07073
Phone: 201/935-2700

Chicago Division

7510 Frontage Road
Skokie, Illinois 60077
Phone: 312/679-8700

Atlanta Division

1898 Leland Drive
Marietta, Georgia 30067
Phone: 404/952-0064

AC7605 GY02

ODYSSEY PRODUCT REGISTRATION CARD



MODEL NUMBER

SERIAL NUMBER

User Identification

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

Last Name

--

First Name Initial

Date product was delivered to user

--	--

Mo.

--	--

Day

--	--	--	--

Year

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

Street No. & Name

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

City

--	--	--

State

--	--	--	--	--

Zip

SELLING DEALER: Please stamp or print your company
Name, address in the space below.

SELLING DEALER:

Complete this card and mail to The N.A.P. Consumer Electronics
Corp., P.O. Box 28, Product Registration Dept., Greeneville, TN, 37743
within 5 days after product delivery.